

SELF SENSING PNEUMATIC MUSCLE

By Mahdieh Nejati

Supervised by Dr Iain Anderson

The Biomimetics Laboratory of the Auckland Bioengineering Institute

23 January- 27 April

2012

MARINE PROPULSION



Oars



Propellers



Biomimetics

Limitations:

- ❖ Lack of maneuverability
- ❖ Lack of obstruction avoidance
- ❖ Lack of flow tracking
- ❖ Corrosion
- ❖ Disturbance to marine life

FISH PROPULSION




Proprioception

- ❖ Avoid obstacles
- ❖ Detect prey
- ❖ Active propulsion and maneuverability

PRIOR ART




SUPERFICIAL SENSING



- ✓ Easy to attach and detach
- ✓ Easy and quick to manufacture
- ✓ Easily damaged
- ✓ Sensing surface only covers a fraction of the actuation area

SENSING PATCH RESULTS



SELF SENSING PAM

- ❖ Self sensing bladder
- ❖ Protected by silicon sheet and nylon mesh
- ❖ Sensing over entire actuation surface
- ❖ Extremely lightweight (10 g)
- ❖ Small dimensions



MANUFACTURING

1. Bladder: Medical grade latex tubing (Qcare 1/2x5/8x1/16)



2. Lubricating bladder inner surface area using baby powder

Paper cone



MANUFACTURING

3. Insert support rod.



4. Protect one electrode connection flap.



MANUFACTURING

5. Electrode Mixture: 1 part carbon black, 16 part kerosene, 4 part RS silicon.

6. Paint electrode with soft bristle brush.

- Consistent electrode surface
- Thin layer
- Minimal inaccuracies


Stand to dry in fume cupboard for at least 1 hour.



MANUFACTURING



7. Remove protective label from first flap while covering the other flap.



MANUFACTURING



8.

- ❖ Dielectric mixture: 1 part RS silicon, 4 part kerocene
- ❖ Danfoss silicon sheet:
 - Width = bladder length
 - Length \approx twice the bladder diameter
- ❖ Brush small amounts on dielectric mixture onto silicon sheet with a small flat soft chisel.
- ❖ Carefully roll the dielectric over the muscle.
- ❖ Secure both ends and edge with a thin stroke of dielectric mixture.

MANUFACTURING

Let dry.

9. Paint second electrode layer.



MANUFACTURING

10. End Fittings:

- ❖ SMC reducer fitting: KQ2R06-10
- ❖ 10mm dia plastic rod



MANUFACTURING

11. Nylon mesh (RS 170-5447)

Sizing is very important:



Diameter $> 1-1.3 \times$ bladder diameter works well



CAPACITIVE SENSING



Self-Sensing PAM Oscilation (0-2bar)



FORCE TEST


$$\diamond F = \frac{P}{A},$$

where F = force,


P = inner pressure,

A = Muscle cross sectional area

$$\diamond F = \frac{200\text{KPa}}{3.14\text{E}^{-4}} \approx 6.4\text{ kg}$$



REPEATABILITY OVER ISOLATED TESTS



FAILURE

- ❖ Failure at pressures greater than 3bar.




ADVANTAGES



- ❖ It does not need an exoskeleton to install rigid sensor, e.g. sliding and rotary potentiometers.
- ❖ Secondly, a higher accuracy and S/N ratio can be obtained by measuring the circumference displacement instead of directly measuring the axial displacement.
- ❖ The default position for the PAM is the relaxed state, as opposed to a pretension state required in past research.
- ❖ The sensor is along the entire circumference of the PAM and thus allows for an average value with reduced measurement error found in other sensors that are locally placed.
- ❖ The sensor is made from thin layers of carbon-silicon rubber which is inherently flexible and lightweight; therefore the flexibility and lightweight properties of the PAM are not lost.

FUTURE DEVELOPMENTS



- ❖ Application as robofish muscle

- ❖ Application as pump and valve

- ❖ Reducing size of dielectric

- ❖ Increasing operational pressure

ACKNOWLEDGMENTS



Big big thanks to everyone at the biomimetics
laboratory, in alphabetic order:

Antoni, Ben, Casey, Daniel, David , Iain, JJ, Sam,
Scott, The coffee machine, Todd, Tom, Tony